

ASSEMBLY INSTRUCTIONS

MODEL NUMBER: L1031 (Table Lamp)

1. Unpack all parts from the carton carefully
2. Place the lamp base (1) on the table.
3. Place the shade (3) onto the lamp head (2).
4. Then use Rim (4) to secure the shade (3) onto the lamp head (2).
5. This lamp uses a Type "B" 40 watt max bulb (5) (not included).
6. This lamp has a gear switch to turn the bulb (ON/OFF).

Important safety instruction:

This table lamp has a polarized plug (one blade is wider than the other). As a safety feature to reduce the risk of electric shock. This plug will fit in a polarized outlet only one way. If the plug does not fit fully in the outlet, reverse the plug. If it still does not fit. Contact a qualified electrician, never use with an extension cord unless plug can be fully inserted. Do not alter the plug.

CAUTION: TO REDUCE THE RISK OF FIRE USE MAXIMUM

40 WATT TYPE B BULB.



ASSEMBLY INSTRUCTIONS

