
ASSEMBLY INSTRUCTIONS FB77-WH/LG/DG Convertible Chair




NOTE TO CUSTOMERS:


- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten, as this may damage the product.
- Please ensure you retain all the product packaging until the item completely assembled.
- Please periodically check all fittings and re-tighten as necessary.
- It is recommended that this item should be assembled by two adults.

Part List




Step 1






Insert and Tighten legs (D) into the seat (A) as shown above. Assemble casters (C) to the seat (A) using screws (E) as shown above.

Step 2



Pull out seat frame ,refer to fig.1. then lift the seat cushion ,refer to Fig.2.

Step 3



The backrest is adjustable to three positions, refer to diagram above.