

ASSEMBLY INSTRUCTIONS MODEL #D48-T: ROUND DINING TABLE



NOTE TO CUSTOMERS:


- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on a dry, soft, smooth and clean surfaces during assembly to prevent any damage. Avoid damp and direct sunlight.
- During assembly do not over tighten the screws or bolts, as this may damage the product.
- Please ensure you retain all the product packaging until the item is completely assembled.
- Periodically check all fitting and re-tighten as necessary.
- Never allow any liquids to remain on your furniture as absorption can cause the wood to warp or finish to de-laminate.
- It is recommended that this item should be assembled by two adults.




Insert the wooden dowels (4) into the designated holes in all table legs (B) until the dowels fit snugly in each hole.

STEP 2

Assemble the table legs (B) one at a time by attaching each leg to the connecting blocks in the table top. Ensure that the wooden dowels in each table leg fit snugly into the table top. Next, align Bolt (1), which is fitted with a Spring Washer (2) and a Flat Washer (3), with the holes in the connecting blocks. Tighten the bolts using the Allen Key (6).





GENTLY LIFT THE TABLE AND PLACE IT UPRIGHT WITH THE ASSISTANCE OF TWO OR MORE ADULTS