


ASSEMBLY INSTRUCTIONS

Style # R1011 Storage Cabinet



NOTE TO CUSTOMERS:

- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten, as this may damage the product.
- Please ensure you retain all the product packaging until the item completely assembled.
- Please periodically check all fittings and re-tighten as necessary.
- Never allow any liquids to remain on your furniture as absorption can cause the wood to warp or the finish to de-laminate.
- It is recommended that this item should be assembled by two adults.

To insert a cam lock: (Please read below instructions before assembling)





Diagram A



1. Insert cam screw into hole as shown in diagram A .





Diagram B



Make sure not to insert the cam screw:
Too deep as shown in figure B as this will cause the
cam screw to be misaligned and unable to
interlock properly.







Diagram C



Also avoid inserting the cam screw too close to the
surface of the hole as shown in figure C, as this will
cause the cam lock to be too loose, and not interlock
properly.




2. Connect the panels together.



ARROW SIGN



3. When inserting the cam lock make sure the arrow
of the cam lock faces the cam screw.











4. To tighten the cam lock turn the cam lock clockwise
90-180 degree or until the arrow is facing opposite
the place cam lock was inserted.

**NOTE: DO NOT USE AN AUTOMATIC
SCREWDRIVER TO TIGHTEN CAM LOCKS.**






Note:

- Read these instructions carefully before assembling.
- Tools required : Phillips screwdriver, flat screwdriver.
- Find a clean, smooth area on which to work , such as a carpet, in order to avoid scratching the wood surfaces.
- Wait to dispose of the packing material until assembly is complete and all parts and hardware are accounted for.
- Two or more people might be required for assembly.

Part List


A1 Quantity of 1 	A2 Quantity of 2 	A3 Quantity of 1 	A4 Quantity of 2 
Top Panel	Side Panel (L&R)	Bottom Panel	Divider (L&R)
A5 Quantity of 5 	A6 Quantity of 6 	A7 Quantity of 2 	A8 Quantity of 2 
Shelf	Front Bar	Back Panel	Back Panel

Hardware List

B1 Quantity of 42 	B2 Quantity of 36 	B3 Quantity of 28 	B4 Quantity of 1 
Wood Dowel	Cam-Lock	Screw	Screw and Anchor
B5 Quantity of 1 			
Anti-tip Kit			

Assembly instruction


Step :1



B1		16pcs
B2		8sets

Assemble Side Panel A2L and Divider A4L to Front Bars A6 and Shevles A5 using Wood Dowels B1 and Camlocks B2.


Step :2



B1		16pcs
B2		8sets


Assemble Side Panel A2R and Divider A4R to Front Bars A6 and Shevles A5 using Wood Dowels B1 and Camlocks B2.

Step :3




Assemble Shelf A5 to Dividers A4(L&R) using Wood Dowels B1 and Camlocks B2.

Step :4



Assemble Bottom Panel A3 to Side Panels A2(L&R) and Dividers A4(L&R) using Wood Dowels B1 and Camlocks B2.


Step :5



B1		4pcs
B2		8sets

Assemble Top Panel A1 to Side Panels A2(L&R) and Dividers A4(L&R) using Camlocks B2 and Wood Dowels B1.

Step :6









B3		28pcs
B5		1set
B6		1set

Wall

- 1). Attached Back Panel A7 to the back of this unit using Screws B3.
- 2). For your safety, please attach this unit to the wall by Anchor with screws B5 and Anti-tip Kit B6.

APPENDIX: Dimension of Hardwares in this AI.

<div>B1</div> <div></div> <div>Wood Dowel</div>	<div>B2</div> <div></div> <div>Cam-bol t</div>	<div></div> <div>Cam-Lock</div>
<div>B3</div> <div></div> <div>Screw</div>	<div>B4</div> <div></div> <div>Bol t</div>	<div>B4</div> <div></div>