

ASSEMBLY INSTRUCTIONS



Style # WR1348 Wine Rack



NOTE TO CUSTOMERS:

- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten, as this may damage the product.
- Please ensure you retain all the product packaging until the item completely assembled.
- Please periodically check all fittings and re-tighten as necessary.
- Never allow any liquids to remain on your furniture as absorption can cause the wood to warp or the finish to de-laminate.
- It is recommended that this item should be assembled by two adults.

To use a cam lock: (Please read below instructions before assembling)



1. Insert cam screw into hole as shown in diagram A .





Diagram B

Make sure not to insert the cam screw:
Too deep as shown in figure B as this will cause the cam screw to be misaligned and unable to interlock properly.







Diagram C


Also avoid inserting the cam screw too close to the surface of the hole as shown in figure C, as this will cause the cam lock to be too loose, and not interlock properly.



2. Connect the panels together.



3. When inserting the cam lock make sure the arrow of the cam lock faces the cam screw.



4. To tighten the cam lock turn the cam lock clockwise 90-180 degree or until the arrow is facing opposite the place cam lock was inserted.

NOTE: DO NOT USE AN AUTOMATIC SCREWDRIVER TO TIGHTEN CAM LOCKS.

Note:

- Read these instructions carefully before assembling.
- Tools required : Phillips screwdriver, flat screwdriver.
- Find a clean, smooth area on which to work , such as a carpet, in order to avoid scratching the wood surfaces.
- Wait to dispose of the packing material until assembly is complete and all parts and hardware are accounted for.
- Two or more people might be required for assembly.




















WARNING:

**Serious or fatal crushing injuries can occur from furniture tip-over.
To help prevent tip-over:**














- Place heaviest item in the lowest drawers.
- Unless specifically designed to accommodate, do not set TVs or other heavy objects on top of this product.
- Never allow children to climb or hang on drawers, doors or shelves.
- Never open more than one drawer at a time. (OR)
- Do not defeat or remove the drawer interlock system.

Use of tip-over restraints may only reduce, but not eliminate the risk of tip-over.


Part List

| | | | |
|---|---|--|---|
| A1.  Shelf Quantity of 1 | A2 (L&R).  Divider Quantity of 2 | A3.  Bottom Panel Quantity of 1 | A4.  Left Side Panel Quantity of 1 |
| A5.  Right Side Panel Quantity of 1 | A6.  Top Panel Quantity of 1 | A7.  Back Panel Quantity of 1 | A8.  Back Panel Quantity of 2 |
| A9.  Cross Shelf Quantity of 2 | A10.  Cross Shelf Quantity of 3 | A11.  Drawer Front Panel Quantity of 3 | A12.  Drawer Side Panel Quantity of 6 |
| A13.  Drawer Back Panel Quantity of 3 | A14.  Drawer Bottom Panel Quantity of 3 | A15.  Adjustable Shelf Quantity of 2 | A16 (L&R)  Door Quantity of 2 |
| A17.  Leg Quantity of 4 | | | |

Hardware List


| | | | |
|---|---|--|---|
| <p>B1</p> <p style="text-align: center;">Quantity of 20</p>  <p>Cam-bolt</p> | <p>B2</p> <p style="text-align: center;">Quantity of 28</p>  <p>Screw</p> | <p>B3</p> <p style="text-align: center;">Quantity of 24</p>  <p>Screw</p> | <p>B4</p> <p style="text-align: center;">Quantity of 20</p>  <p>Wood Dowel</p> |
| <p>B5</p> <p style="text-align: center;">Quantity of 5</p>  <p>Knob</p> | <p>B6</p> <p style="text-align: center;">Quantity of 8</p>  <p>Shelf Support</p> | <p>B7</p> <p style="text-align: center;">Quantity of 2</p>  <p>Magnet with Screw</p> | <p>B8</p> <p style="text-align: center;">Quantity of 4</p>  <p>Bolt</p> |
| <p>B9</p> <p style="text-align: center;">Quantity of 4</p>  <p>Pin</p> | <p>B10</p> <p style="text-align: center;">Quantity of 3</p>  <p>Stopper with Screw</p> | <p>B11</p> <p style="text-align: center;">Quantity of 8</p>  <p>Wood Dowel</p> | <p>B12</p> <p style="text-align: center;">Quantity of 1</p>  <p>Wall Anchor with Screw</p> |
| <p>B13</p> <p style="text-align: center;">Quantity of 1</p>  <p>Anti-tip Kit</p> | | | |


Step 1



Attach Stoppers B10 to the top of Shelf A1 using included Screws B10.


Step 2




B7 :  2sets

1. Attach Magnets B7 to the bottom of Shelf A1 using included Screws B7.
2. Attach Shelf A1 to Dividers A2(L&R) as above drawing shown.

Step 3






B4 :  4pcs

B1 :  4pcs

Assemble Side Panels A4&A5 to Shelf A1 using Wood Dowels B4, Cam-bolts B1 .



Step 4


- B8 :  4pcs
- B11 :  8pcs



Assemble Legs A17 to the bottom of Bottom Panel A3 using Wood Dowels B11 and Bolts B8.

Step 5

- B4 :  8pcs
- B1 :  8pcs




Assemble Bottom Panel A3 to Dividers A2(L&R) and Side Panels A4&A5 using Wood Dowels B4, Cam-bolts B1 .

Step 6

B4 :  8pcs


B1 :  8pcs



Assemble Top Panel A6 to Dividers A2(L&R) and Side Panels A4&A5 using Wood Dowels B4, Cam-bolts B1


Step 7

B2 :  28pcs




Attach Back Panels A7&A8 to the back of this unit using Screws B2.

Step 8




1. Attach Drawer Side Panels A12 to Drawer Back Panel A13 using Screw B3.
2. Insert Drawer Bottom Panel A14 into the grooves on Drawer Side Panels A12 and Drawer Back Panel A13.
3. Attach Drawer Front Panel A11 to Drawer Side Panels A12 using Screws B3.
4. Attach Drawer Knob B5 to Drawer Front Panel A11 using included Bolt B5.


Step 9



Insert the drawers into this unit as above drawing shown.




Step 10


B6 :  8pcs




1. Attach Cross Shelf A9&A10 as above drawing shown and hold them carefully into the middle space of the cabinet.
2. Insert Shelf Supports B6 into the holes on Dividers A2(L&R) and Side Panels A4&A5.
3. Place Adjustable Shelves A15 on the top of Shelf Supports B6.



Step 11

B5 :   2sets
 B9 :  4pcs














1. Insert Door Pins B9 into the holes on the bottom of Doors A16, then connect Doors A16 to Bottom Panel A3 as Fig.1.
2. Insert Door Pins B9 into the holes on the top of Doors A16, then press down Door Pins B9 see Fig.2, and insert the Doors A16 carefully into the cabinet with the Door Pin B9 popping up into the holes on Shelf A1.
3. Attach Knobs B5 to Doors A16 using included Bolts B5.



- B12 :  1set
- B13 :  1set

For your safety, please attach this unit to the wall by Anchor with Screw B12 and Anti-tip B13.

APPENDIX: Dimension of Hardwares in this AI.

| | | |
|---|---|--|
| <p>B1</p>  <p>Cam-bolt</p> |  <p>Cam-lock</p> | <p>B2&B7</p>  <p>Screw</p> |
| <p>B3</p>  <p>Screw</p> | <p>B4</p>  <p>Wood Dowel</p> | <p>B5</p>  <p>Bolt for knob</p> |
| <p>B8</p>  <p>Bolt</p> | <p>B10</p>  <p>Screw</p> | <p>B11</p>  <p>Wood Dowel</p> |
| <p>B12</p>  <p>Screw</p> | <p>B13</p>  <p>Screw</p> | |