


ASSEMBLY INSTRUCTIONS









Style#K571 Bakers Rack









NOTE TO CUSTOMERS:

- For ease and speed of assembly we recommend that before you commence each step of the assembly that you identify all the parts required to complete that step.
- We recommend that where possible you allow sufficient space to assemble the item as close as possible to the place where it will be once assembled.
- For the protection of your furniture we recommend that the product is placed on protected surfaces during assembly to prevent any damage.
- During assembly do not over tighten, as this may damage the product.
- Please ensure you retain all the product packaging until the item completely assembled.
- Please periodically check all fittings and re-tighten as necessary.
- Never allow any liquid to remain on your furniture as absorption can cause the wood to warp or the finish to de-laminate.
- It is recommended that this item should be assembled by two adults.


Part List


A1  Quantity of 2 Lower Side Frame	A2  Quantity of 1 Upper Left Side Frame	A3  Quantity of 1 Upper Right Side Frame	A4  Quantity of 2 Lower Net Rack	A5  Quantity of 1 Upper Connect Bar
A6  Quantity of 1 Lower Connect Bar	A7  Quantity of 1 Middle Panel	A8  Quantity of 1 Top Panel		

Hardware List

B1  Quantity of 4 Bolt	B2  Quantity of 10 Bolt	B3  Quantity of 2 Bolt and Nut	B4  Quantity of 4 Screw	B5  Quantity of 2 Anchor and Screw	 Allen Key
---	--	---	--	---	---

STEP 1


B1  2pcs



Assemble Lower Side Frames A1 to Lower Connect Bar A6 using Bolts B1.
Note: Please do not tighten Bolts B1 until Step 5.

STEP 2


B2  8pcs



Insert and assemble Lower Net Racks A4 to Lower Side Frames A1 using Bolts B2 as shown above.


Note: Please do not tighten Bolts B2 until Step 5.

STEP 3




Put Middle Panel A7 onto Lower Side Frames A1, then insert Upper Side Frames A2&A3 to Lower Side Frames A1 as shown above.

STEP 4




- 1). Assemble Upper Connect Bar A5 to Upper Side Frames A2&A3 using Bolts B1.
 - 2). Assemble Upper Side Frames A2&A3 to Lower Side Frames A1 using Bolts B2.
- Note: Please do not tighten Bolts B1&B2 until Step 5.


STEP 5



- 1). Assemble Upper Side Frames A2&A3 to Middle Panel A7 and Lower Side Frames A1 using Bolt and Nuts B3 as shown above.
 - 2). Assemble Top Panel A8 to Upper Side Frames A2&A3 using Screw B4.
- Note: Please tighten all bolts at this point.






STEP 6

B5  2sets



For your safety, please attach this unit to the wall by Anchor and Screws B5.

APPENDIX: Dimension of Hardwares in this AI.

<p>B1.</p>  <p>Bolt</p>	<p>B2.</p>  <p>Bolt</p>	<p>B3.</p>  <p>Bolt</p>	<p>B4.</p>  <p>Screw</p>
<p>B5.</p>  <p>Screw</p>			